

Campo

|                                           | 2025-12 |    |    |    |   | 2026-1 |   |   |   |   | 2026-2 |   |   |    |    | 2026-3 |    |    |    |    | 2026-4 |    |    |    |    | 2026-5 |  |  |  |  |
|-------------------------------------------|---------|----|----|----|---|--------|---|---|---|---|--------|---|---|----|----|--------|----|----|----|----|--------|----|----|----|----|--------|--|--|--|--|
|                                           | 49      | 50 | 51 | 52 | 1 | 2      | 3 | 4 | 5 | 6 | 7      | 8 | 9 | 10 | 11 | 12     | 13 | 14 | 15 | 16 | 17     | 18 | 19 | 20 | 21 | 22     |  |  |  |  |
| Software                                  |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Campo                                     |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| implement hwdata stterm command           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| create custom targets to cmake file (...) |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| implement font converter                  |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Biwak                                     |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| implement SPI DMA transmit                |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Implement DMA USB                         |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Clean up heart-beat-LED-code              |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Test implementation of eventLoop (...)    |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Document tipps and tricks                 |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Verify dynamic sleep                      |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| MAX31855: Negative values are not (...)   |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Biwak - v2.17.0                           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| use 128 bit UID                           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Implement dynamic sleep                   |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Blink modes: Use slower timings (...)     |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Host GUI: Pressing button (...)           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Allow more retain containers (...)        |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Retain: Use bigger data type (...)        |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| CRC: Make methods const.                  |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Touch: Whole processing is (...)          |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Biwak - v2.18.0                           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Simulate touch display on (...)           |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Cordyceps                                 |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Cordyceps - v99.0.0                       |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Show marker in plots                      |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |
| Show event marker in plots                |         |    |    |    |   |        |   |   |   |   |        |   |   |    |    |        |    |    |    |    |        |    |    |    |    |        |  |  |  |  |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| <p><b>Kokon</b></p> <p>Check board id and revision before (...)</p> <p><b>libcampo</b></p> <p>bringup: Create test to write internal (...)</p> <p>unit tests: parse hwinfo files</p> <p>campo.sh: verify "release" function</p> <p>campo.sh: add changeLogSubmodules</p> <p>hwdata: clean up</p> <p>Vagus: CAN: use filters</p> <p>libcampo - v0.99.0</p> <p>Bringup: verify/calibrate (...)</p> <p><b>liblepto</b></p> <p>CMake: No install target</p> <p>Make it compile for host computer</p> <p>liblepto - v0.6.1</p> <p>Implement CONFIG_LEPTO_RING_CUSTOM_DATA</p> <p>Add unit tests for strings.</p> <p>Support expandable lists</p> <p>CList: Add method for searching (...)</p> <p><b>libocelli</b></p> <p>Use changeable framework</p> <p>libocelli - v99.0.0</p> <p>implement png reader</p> <p><b>libscapus</b></p> <p>bme680: calculate absolute humidity</p> <p><b>theme_noto</b></p> <p>theme_noto - v0.2.0</p> <p>create const icon references</p> |  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|